



Coordinate Mode



- To change the coordinate mode option, choose the Coordinate Mode Box and choose a Coordinate mode from the menu



Mode	Display	Description
Absolute	(ABS)	Coordinates are the X and Y distances from the drawing origin (0,0)
Relative	(REL)	Coordinates are the X and Y distances from the last point clicked. In other words, the last point defined is treated as (0,0)
Polar Relative	(POL)	Coordinates are the angle and distance from the last point clicked.
Polar Absolute	(PAB)	Coordinates are the angle and distance from the drawing origin.

