



IntelliCAD 2001 ToolBars - Quick Reference Guide

Standard Toolbar

































Draw Toolbar



IntelliCAD 2001 ToolBars - Quick Reference Guide

Modify Toolbar

	Move		
	Copy		
	Parallel		
	Scale		
	Rotate		
	3D Rotate		
	Mirror		
	3D Mirror		
	Array		
	3D Array		
			Extend Flyout
	Break		Extend
	Join		Edit Length
	Trim		Stretch
	Flatten		
	Align		
	Extend Flyout		Measure Flyout
	Measure Flyout		Measure
	Chamfer Flyout		Divide
	Edit Polyline		
	Edit Text...		Chamfer Flyout
	Explode		
	Change		Chamfer
	Properties...		Fillet

IntelliCAD 2001 ToolBars - Quick Reference Guide

Dimensioning Toolbar



- Linear
- Aligned
- Angular
- Leader
- Rotated
- Circle Flyout
- Baseline
- Continue
- Ordinate
- Tolerance
- Make Oblique
- Edit Dimension Text
- Rotate Dimension Text
- Reposition Dimension Text
- Restore Text Position
- Apply Style
- Save Style
- Restore Style

Circle Flyout



- Centre Lines
- Diameter
- Radius

Draw 3D Toolbar



- Wedge
- Pyramid
- Box
- Cone
- Cylinder
- Sphere
- Dish
- Dome
- Torus
- Mesh
- Mesh **Flyout**
- Surface **Flyout**

Mesh Flyout



- Polyface Mesh
- 3D Face
- Polygon Mesh


Surface Flyout




- Revolved Surface
- Ruled Surface
- Extruded Surface
- Coons Surface

IntelliCAD 2001 ToolBars - Quick Reference Guide


Inquiry Toolbar




Settings



Colour Flyout


















Entity Snaps
































IntelliCAD 2001 ToolBars - Quick Reference Guide

Tools Toolbar


	IntelliCAD Explorer
	Visual Basic for Applications
	Group...
	Record Scripts...
	Stop Recording
	Run Script
	Create Block
	Save Block to Disk
	Make Snapshot...
	View Snapshot...
	Define Attributes...
	Edit Block Attributes...
	Attribute Display
	Extract Attribute
	External Reference

View Toolbar

	Redraw Flyout		Redraw Flyout		Pan Flyout
	Pan		Redraw		Real-Time Pan
	Zoom In		Redraw All		Real-Time Zoom
	Zoom Out		Regen		Real-Time Sphere
	Zoom Window		Regen All		Real-Time X
	Zoom Extents				Real-Time Y
	Zoom Flyout				Real-Time Z
	Pan Flyout	Zoom Flyout			
	Dynamic View Control		Zoom Previous		
	Preset View Ports		Zoom All		
	Plan View		Zoom Left		
	Define View		Zoom Center		
	Save / Restore View				
	Workspace				
	Viewports				
	Paper Space Views				

IntelliCAD 2001 ToolBars - Quick Reference Guide

Entity Data Toolbar



- Create or Edit Entity Data
- Copy Entity Data
- Move Entity Data
- Delete Entity Data
- Re associate Entity Data

Rendering Toolbar



- Hide
- Shade
- Render
- Full Render
- Materials...
- Backgrounds...
- Lighting...
- Render Settings...

Image Enabler Toolbar



- Attach Raster Image
- Image Management
- Image Adjust
- Image Transparency
- Image Quality
- Display Image Frame
- Draw Order